

Simple EPDM-roofing foil installation

Roofing in 90 minutes

Start/ Preparations

This Quick Start Guide describes the seamless installation of EPDM roofing foil on flat roofs, as for additions, carports or garages using water-based adhesive surface in wet bonding process on wood (or permeable material). Mind. 24 h > 5 ° C. Roof free from dirt and sharp objects (roof brush off).



After 10 minutes

Lay foil smooth and completely on the roof and let it rest for 30 to 60 minutes depending on the ambient temperature to allow pack to relax wrinkles.



After 40 minutes

Approx. 50% of the foil hit back (eg, in the piece or in broad loops). Subsequently, the water-based adhesive evenly with a paint roller to roll out on the ground (in the edge region is not going to a strip brush), approximately 0.20 l / m when using a short nap paint roller-velor.



After 60 minutes

Pull the folded-back foil on the adhesive part is painted with a broom and swipe from the center of the roof of the slide smooth, so that the wrinkles are removed.

Repeat the procedure with the remaining part of the foil.



After 80 minutes

The foil beat back the unglued edge areas and the wedge pile with adhesive foil and sprinkle on the edge of the area smooth "sweep".

Depending on the design of the roof edge is now the film as be mechanically fastened with a roof edge profile. Not compromise the film under tension.



Finishing after 90 minutes